Safe-SitterTM Replacement Harness Instructions Please Read All Instructions Before Beginning the Installation.

Tools Required:

Screwdriver



Allen Key 1/8"



Remove the Safe-Sitter from the wall. Lie the Safe-Sitter on a flat surface.

Remove the machine screws from the back of the Safe-Sitter and from the bottom of the seat door.



 Back of the Safe-Sitter Bottom of the seat door.



Pull old harness from all cavities.



Pass the new harness ends through all of the cavities. Make sure that the Safe-Strap logo on the child resistant buckle is facing to the front.



Secure the harness to the Safe-Sitter with the machine screws you previously removed. Tighten machine screws on the back of the Safe-Sitter and on the bottom of the seat.



Back of the Safe-Sitter Bottom of the seat door. —



Pull harness to assure that it is tight. Reinstall Safe-Sitter onto wall following the Safe-Sitter installation instructions.

For Questions or Technical Assistance call 800.356.7796

SAFESTRAP.COM 800.356.7796 973.442.4623 info@safestrap.com